WK-Series (White Knight[™]) Series Gas Purifiers

Features and Benefits

- For point-of-use to bulk flow specialty gas purification
- Highest Lifetimes
- Best Impurity Removal Efficiencies
- Removes critical contaminants to sub part-per-billion levels
- Patented built-in poppet valves at purifier inlet and outlet for purifiers filled with: OMX, OMX-Plus, and In2Go
- Enhances manufacturing process economy and improves equipment performance
- Provides consistently high purity gas under fluctuating inlet impurity conditions
- Improves component lifetime and reduces particle generation by removing moisture from corrosive gases
- Compact Footprint; Inline design
- Easy to install & operate
- No heating or cooling required
- Quick start up
- All metal parts, Type 316L stainless steel, or Nickel 200
- Economical, Low Cost of Ownership

Specifications

- 0.003 µm filter with 99.9999999% retention (PTFE or 316L SS)
- Internal surface finish < 15 μ in R_a
- Maximum operating temperature is 70°C

Connections

• Male inlet and outlet connections, 1/4" VCR - compatible

Options

- Inlet and outlet isolation valves
- Three-valve manifold with isolation and bypass valves allows disconnection of purifier without interrupting process gas flow

Purifier Models

Model No.	Maximum Recommended Flow Rate*	Maximum Allowable Working Pressure
WK-70F	5 slpm (0.3 NM³/hr)	1,000 psig (7 Mpa)
WK-75F	5 slpm (0.3 NM ³ /hr)	1,000 psig (7 Mpa)
WK-500F/P	60 slpm (3.6 NM ³ /hr)	500 psig (3.5 Mpa)
WK-2500F/P	300 slpm (18 NM³/hr)	500 psig (3.5 Mpa)

* Applies to designs without built-in poppet valves.

Overview

NANOCHEM® WK-Series (White Knight[™]) purifiers offer the highest lifetimes and the best impurity removal efficiencies in a very economical design. The in-line design enables a very compact footprint and allows drop-in replacement of competing hardware designs. WK-Series are available in a number of sizes ranging from 55-ml for point-of-use applications to 9-liters for bulk gas purification. Flow rates range from 3 slpm (0.2 NM³/hr) to 300 slpm (18 NM³/hr).



Gas Type	Impurities Removed
Nitrogen (N ₂), Argon (Ar),	< 100 ppt H ₂ O, O ₂ , CO ₂ LDL
other inerts	< 1 ppb CO*
	< 100 ppt NMHC (with OMX-Plus [™]) LDL
	$NO_{x'} SO_{x'} H_2S$
Ammonia (NH₃)	< 100 ppt H_2O , O_2 , CO_2 in inert gas LDL
	< 1 ppb CO*
	< 45 ppb H ₂ O in ammonia LDL
	NH ₃ -CO ₂ complexes, SiH ₄ , Siloxanes, GeH ₄ , H ₂ S
Silane (SiH ₄)	< 100 ppt H_2O , O_2 , CO_2 LDL
	< 1 ppb CO*
	Chlorosilanes, disilane, siloxanes, arsine, phosphine
Hydrogen (H_2), Methane CH_4),	< 100 ppt H_2O , O_2 , CO_2 LDL
Ethane (C_2H_6), other HC	< 1 ppb CO*
	NO _x , SO _x , H ₂ S
Sulfur Hexafluoride (SF ₆),	< 100 ppt H_2O , O_2 , CO_2 in inert gas LDL
Carbon Tetrafluoride (CF ₄),	< 10 ppb O_2 , H_2O in sulfur hexafluoride LDL
other fluorocarbons	
Oxygen (O_2) , Carbon Dioxide (CO_2) ,	< 10 ppb H ₂ O
Nitrous Oxide (N ₂ O)	
Carbon Monoxide (CO)	Metal Carbonyls: Fe, Ni
Corrosives	< 1 ppb H ₂ O in inert gas
(HCI, HBr, CI_2 , SiH_2CI_2 , $SiHCI_3$, BCI_3)	$< 100 \text{ ppb H}_2\text{O} \text{ in HBr}$ LDL
	$< 150 \text{ ppb H}_2\text{O} \text{ in HCl}$
	Volatile Metals: Fe, Mo, Cr, Ni, Mn, Ti

LDL - Lower Detection Limit by State-of-the-Art Analytical Instrumentation

NMHC – Non-methane Hydrocarbons

*NOTE: CO is removed efficiently by OMX & OMX-Plus^ $\mbox{\tiny M}$ media at low flow rates (recommend 1/10 of normal flow rate)

For a detailed list of purification media and impurities removed, refer to the Purification Media Table in Nanochem® Purification Solutions Brochure.



Pressure Drop



Dimensions



Note: Purifiers are shown in horizontal position for illustration purposes only. A vertically-oriented installation is preferred.

Models WK-75F, WK-500F and WK-2500F have a 0.003 µm particle filter

Equipment Technology Center

166 Keystone Drive Montgomeryville, PA 18936 Tel: 800-828-4313 • Fax: 215-619-0458 Email: Info@mathesongas.com

Specifications are subject to change. Please check www.mathesongas.com for most current information.

Copyright 2015 Matheson Tri-Gas, Inc. All Rights Reserved.

All contents of this document are subject to change without notice and do not represent a commitment on the part of Matheson Tri-Gas, Inc. Every effort is made to ensure the accuracy of this information. However, due to differences in actual and ongoing operational processes and product improvements and revisions, Matheson Tri-Gas, Inc. cannot guarantee the accuracy of this material, nor can it accept responsibility for errors or omissions. This document is intended to serve as a general orientation and cannot be relied upon for a specific operation. No warranties of any nature are extended by the information contained in these copyrighted materials.

All names, products, and services mentioned herein are the trademarks or registered trademarks of their respective organizations and are the sole property of their respective owners. Matheson and the Matheson logo are registered trademarks of Matheson Tri-Gas, Inc.

White Knight is a trademark of Matheson Tri-Gas, Inc. NANOCHEM is a registered trademark of Matheson Tri-Gas, Inc. VCR is a registered trademark of Swagelok Company Printed in USA PB037 R06/19

